



Acer Iconia Tab 8 A1-860 Battery Replacement

This guide shows you how to open the tablet to remove and replace the battery.

Written By: Stephanie Nelson



INTRODUCTION


If your device no longer holds a charge, this guide shows you how to fix the problem.



TOOLS:


- [iFixit Opening Tools](#) (1)
 - [Spudger](#) (1)
-

Step 1 — Rear Case



- Insert the plastic opening tool into the seam between the back case and the display.
- Work the plastic opening tool around the seam until the rear case separates from the display.

Step 2




- Separate the rear case and place the tablet face side down.

Step 3 — Battery



- Using a spudger, work the tool under the battery connector located above the battery on the left side, and lift it free.

Step 4



- Pull firmly on the black tabs, located at the top left and bottom right of the battery.
- ⓘ The clear adhesive strips attached to the tabs are quite stretchy. Don't give up; keep pulling the tabs until the battery releases. The strips will not be reusable.
- Remove the battery.

To reassemble your device, follow these instructions in reverse order.

